





# Measuring Instructions

For accurate measurements please use a metal tape measure, and take measurements in centimeters, to the nearest 0.1cm.

- All of our blinds can be fixed into the face of the window frame or wall, or into the top of the lintel - allowing you total control of the depth your blind can be positioned in the depth of your window recess.
- Choose whether you want the blinds to hang inside or outside the window recess.
- Please check for the proximity of adjacent walls, furniture, window handles etc. when measuring for your blinds.



**Recess**



**Exact**

## Aftercare

Look after your blinds by following the straightforward operating instructions below.

### Operating

- One cord on the Wooden Venetian operates the height of the blind.
- The other cord operates the angle of the slats.
- To raise the blind pull the cord down until the blind reaches your desired height.
- To lower the blind pull the cord across the face of the blind to release the cordlock and let cord slide through your fingers.
- To adjust the angle of the slats pull the other cord until they are at the desired angle.
- When raising or lowering the blind slats should be in the open position.
- Please note: Wooden Venetians do not close totally - it is the nature of the product.

### Cleaning

- Your Wooden Venetians should only be cleaned with a dry non-lint cloth.

NB: The manufacturer will not accept responsibility for damage to blinds caused by misuse. Fitting items may vary depending upon type of fitting requested.